

LET'S GET IT TOGETHER



Main Frame Joint


- a. Position both halves of frame so that the joint lines up to its mating side
- b. Push both halves of the frame completely together.
- c. While holding joint snugly insert frame bolt and hand tighten.
- d. Use allen wrench (provided in front cap) and tighten completely*

***WARNING:** Failure to tighten properly could cause an accident resulting in serious injury.



Cable Connector Assembly:


- e. While holding both ends of the cable connector align the pin of the front with the slot of the rear.
- f. Push pin all the way into slot and turn until pin is fully seated in locked position.



5

6

LET'S GET IT TOGETHER



Front Wheel Assembly (non-folding only)

- a. Hold bike in one hand and use other hand to hold wheel.
- b. Position front wheel so that brake disc is directly below slot in brake caliper. Slide front wheel into place.
- c. Making sure axle is fully seated in fork,* hold skewer nut (1) while turning skewer bolt (2) clockwise with wrench. (provided in front cap)

***WARNING:** Failure to tighten properly could cause an accident resulting in serious injury.



Foldable Pedal

- a. Pedal in folded position. Find Pedal Slide-Lock (1)
- b. While pressing down on Pedal Slide-Lock, fold pedal up into horizontal position.
- c. Pedal in locked position. To fold pedal, reverse steps a and b.



7

8